


SURROUND YOUR HOME WITH A CURTAIN OF WARMTH



CAVALIER BASEBOARD HEAT puts the heat where it is needed most—between the household and the cold outside... gently radiates and circulates warmth from weather-side walls, from floor level. The simplest, most efficient heating system ever developed!

WALL-TO-WALL COMFORT AT ALL LEVELS!
NO HOT OR COLD SPOTS... NO CHILLY FLOORS


Cavalier[®] ELECTRIC BASEBOARD HEAT AUTOMATIC

FOR NEW HOMES OR OLD. Cavalier Baseboard Heat is installed where you would ordinarily use wood Baseboard—but on weather-side walls primarily. Blends unobtrusively with any room finishing and is specially treated for easy painting if desired. For new homes or old—Cavalier Baseboard is easily installed—requires no extensive work prior to installation.

THE GENTLEST HEAT IN THE WORLD! So gentle, a child can touch it. Place furniture against it without harm. Only Cavalier Baseboard Heat stays below 125° (F.) surface temperature.

INDIVIDUAL ROOM HEAT CONTROL. Thermostat in each room maintains the desired temperature... automatically. Here is zone control at its best. The exact heat wanted is chosen by rooms, not by sections of the home. For example, have it mild in working areas, warmer in living room or nursery. Warmth is supplied evenly and quickly. Have comfort just as you want it from the first chilly autumn days, through icy winter weather. Even on cool spring evenings, it provides heat when needed—the accurate thermostatic control does all the work!


MAKES DECORATING EASY. No floor or wall space is lost. Place furniture to fit your decorating plans—Cavalier Baseboard won't interfere... and Cavalier Heat is the cleanest you can have, keeps your rooms looking bright and fresh.



Heat rises so it makes sense to put heat into the room as low as possible. It's cold outside... so it makes sense to put your heat

between you and the weather. Cavalier Electric Baseboard gives you heat at floor level along the outside wall... and does it automatically.

HOW CAVALIER BASEBOARD WORKS



Cavalier Baseboard is supplied in 32 and 48 inch sections with finishing ends and corner pieces. It is quickly installed in new homes or existing construction without tearing into the walls. Placed at floor level on weather-side

walls, it conforms with sound engineering principles to give you the most efficient heating ever developed. Cool air enters baseboard at floor level. Inside heater, the air is channeled over and around the heating element by Cavalier's exclusive zig-zag baffle that assures air being fully subjected to the heat. The warmed air rises and comes out from top. A "secondary" air current flows from the top of rear air passage. This extra flow picks up

the heat that otherwise would be lost into the wall and brings it out into the room where it is needed most. Gentle radiant rays combine with draftless air circulation to give you balanced heat, wall-to-wall comfort at all levels. No moving parts to wear out—no noise, no fuss, no bother. All parts accessible at all times—no worry about costly replacement and construction problems. No waste—100% efficient—you get all the heat you buy!



YOUR LICENSED ELECTRICAL CONTRACTOR IS YOUR CAVALIER DEALER
SEE THE YELLOW PAGES IN YOUR DIRECTORY FOR HIS PHONE NUMBER
HE WILL BE GLAD TO "TALK IT OVER" WITH YOU




U.L. APPROVED

If you are building, buying or remodeling, you can be assured of greater comfort and convenience with Cavalier

See Or Phone Your Local Electric Contractor For Complete Information




MAKES A COMPLETE LINE OF AUTOMATIC ELECTRIC HEATERS
THERE IS A STYLE AND SIZE FOR ANY NEED




WALL INSERT

Easy to install. Cleaned in 3 minutes without removing a single screw. 2 inches lower to fit under windows. 1, 1.5, 2, 2.5, 3, 4 and 5 KW sizes.




SURFACE MOUNTED

Similar to Cavalier Wall Insert Heaters but designed to mount ON the wall instead of IN the wall. Available in 1.5, 2, 3 and 4 KW sizes.



PORTABLE

For the entire home or hard to heat rooms. No installation necessary except providing suitable outlets. Heavy duty. Popular 2, 3 and 4 KW sizes.



FLOOR FURNACES

Fully automatic. Hinged elements swing up for easy cleaning. Easy to install. Only 13 1/2" deep. Two sizes: 5 and 8 KW.



BATHROOM

Automatic, full chrome finish wall insert. Designed for high humidities. 1.5 KW, 230/240 volts. Also non-automatic model, chrome grille and reflector. 1.25 KW, 115/120 volts.