




- 4 Join Front & Back:** Align **(A)** & **(B)**, pattern sides together. Stitch $\frac{1}{4}$ " (6mm) seam along top edge, backstitch for strength.




- 5 Flip & Iron:** Open and flip along top seam so that pattern sides are facing out. Iron along top edge.



- 6 Top Stitch Nose Wire Pocket:** As shown below. Backstitch for strength all seams.



- 7 Add Straps:** Add bias tape or body fabric straps as shown.




Making Straps

1. Cut strips of fabric, does not have to be on the bias. $1\frac{1}{2}$ " - 2" Wide x 36-38" Long

2. Fold in half lengthwise and iron
3. Fold each side in toward center and iron
4. Fold along center and iron again.

The strap cross section should look like this:



$\frac{3}{8}$ " - $1\frac{1}{2}$ "
(10-13mm)

Check For Pins!

- 8 Finished!** Awesome! Please check the Central Oregon Mask Makers Facebook page for collection & drop-off updates and details.

- ! Be Safe!** It is very important to sanitize DIY sewn masks prior to use. Please do not be a vector!